


SVMi E-Series Voicemail Quick Reference Guide



Hampton Roads Communication Technologies (HRCT) provides quality business telecommunications solutions to companies and organizations throughout the Hampton Roads Virginia cities of Virginia Beach, Chesapeake, Norfolk, Portsmouth, Suffolk, Newport News and Hampton, north into Williamsburg and south into the Outer Banks of North Carolina. HRCT keeps your company connected.

Hampton Roads Communications Technologies 2023 High Street, Portsmouth, Virginia 23704 Tel: 757.399.3350 Fax: 757.397.3405



Accessing Your Mailbox (Subscriber Services Menu)

From Your Desk

 Press the button labeled MESSAGE or VMMSG 	
OR	
Dial SVM Access Code:	
(You will be prompted to enter your Passcode)	
Enter your Password:	
(Default Password: 0000)	
From Off-Site (Home, Cell Phone)	
Dial the phone number that is answered by the SVM	
(Your Company's Main Greeting)	

• At the Main Greeting dial [#] plus your Subscriber (or Mailbox) number. (Subscriber and Mailbox Number usually match your extension number)

(Default Password: 0000)


From Another Subscriber's Phone

Enter your Password: _____

- Press the button labeled MESSAGE or VMMSG or dial SVM Access Code.
- Dial [Q] followed by [#] and your Extension / Mailbox Number.
 (You will be prompted to enter your Passcode)
- Enter your Password: _____(Default Password: 0000)

Alternate Off-Site for DID Users (Home, Cell Phone)

- Dial your DID phone number.
 (Your Personal Greeting will answer in approximately 4-6 rings)
- During your Personal Greeting dial [#] directly followed by your password.
 (Default Password: 0000)



Samsung Voicemail Services Menu

NOTE: All options shown MAY NOT be authorized. If an option is not authorized, please speak to your System Administrator.

First Time Easy Set-Up

After log in, set up the following five options for optimum performance.

	Change Your Password: [#][7][1
1	Required to Log In as a Subscriber. Password length can be from 1 to 8 digit Default password is 0000.
	Record Your Name: [#][7][2
2	This recorded name plays to your callers when they are transferred through th Auto Attendant. The Automated Directory also plays your recorded name s callers receive the correct spelling.
	Enter Your Dial-By-Name Directory Name:[#][7][3
3	You are asked to first spell, enter and accept your Last Name, then your First Name on the Telephone Keypad. The Automated Directory uses the feature for callers who do not know your extension number but do know your name.
	Record Your Primary (No-Answer) Greeting:[5][1
4	This Personal Greeting plays to your callers when you do not answer you phone*.
	Record Your Mailbox Greeting: [5][7
5	This Greeting plays when a Primary Greeting is not recorded and/or a call transferred directly into your Mailbox.

^{*}There are other Personal Greetings available that can be scheduled to play for Busy, Forward All (DND), and Night Call Conditions. Ask your System Administrator for more information on Call Condition Greetings.

Quick Reference Index —

AUTO PLAY OF MESSAGE INFORMATION[6][6]
Time & Date Stamp Information. This option can be turned on/off.
AUTO PLAY NEW MESSAGES[6][5]
Plays new messages after you log in. This option can be turned on/off.
DIRECT CALL*
Used for placing outgoing calls while logged in.
EXTENDED PROMPTING[#][7][4]
This option can be turned on/off.
FIND ME*[4][6]
Calls you at a series of numbers in your stored number list.
FOLLOW ME*[4][1]
Changes the number where you are taking your calls.
LISTEN TO NEW MESSAGES[1]
LISTEN TO SAVED MESSAGES[3]
MESSAGE ALERT*[6][1]
When enabled, the system calls to let you know you have new messages. This option can be turned on/off.
PAGER NOTIFICATION*[6][2]
When enabled the system will call your Pager to let you know you have new messages. This option can be turned on/off.
QUICK MEMO[#][MAILBOX #]
Quickly send a message to another Subscriber.
RECORD AND SEND A MESSAGE[2]
REMINDER [#][#]
Quickly send a message to yourself.
STORED TELEPHONE NUMBERS*[#][2]
Enter a list of numbers used by Follow Me, Find Me, and all Notifications.
UNDELETE MESSAGES[6][3]
Deleted messages can be recovered any time before Daily Maintenance time, scheduled by the System Administrator. The default time is 3 a.m.

^{*}Must be Authorized by System Administrator.



Functions While Listening to a Message



Functions While Recording and Sending a Message

